

Leafony / STM32 Pin assign

Table for Leafony / STM32 Pin assign showing pin assignments for AP03 STM32 MCU (STM32L452RE16) with columns for No., Name, Port, Function, and various peripheral functions like USB, BLE, 4-Sensors, etc.

Legend for Leafony / STM32 Pin assign: Green for system-related, Yellow for external circuit use.

Leafony / STM32 Pin assign

Table for Leafony / STM32 Pin assign showing pin assignments for AP03 STM32 MCU (STM32L452RE16) with columns for No., Name, Port, Function, and various peripheral functions like USB, BLE, 4-Sensors, etc.

Legend for Leafony / STM32 Pin assign: Green for system-related, Yellow for external circuit use. Includes note: \* : STM32は、PA2の割り込みで wakeup

Leafony / STM32 Pin assign

Table for Leafony / STM32 Pin assign showing pin assignments for AP03 STM32 MCU (STM32L452RE16) with columns for No., Name, Port, Function, and various peripheral functions like USB, BLE, 4-Sensors, etc.

Legend for Leafony / STM32 Pin assign: Green for system-related, Yellow for external circuit use.

Leafony / AVR Pin assign

Table for Leafony / AVR Pin assign showing pin assignments for AP03 STM32 MCU (STM32L452RE16) with columns for No., Name, Port, Function, and various peripheral functions like USB, BLE, 4-Sensors, etc.

Legend for Leafony / AVR Pin assign: Green for system-related, Yellow for external circuit use. Includes note: \* : ATmega328は、INT0端子(2番ピン)の割り込みで wakeup